# 机动区冲突多发地带运行要求 HOT SPOT PROCEDURE

机动区冲突多发地带位置见ZSQD AD2. 24-1, AD2. 24-2: Refer to ZSQD AD2.24-1, AD2.24-2 for Hot Spots location.

为减少运行差错,降低地面冲突和跑道入侵 事件的发生概率, 在机场活动区内运行的航 空器需严格按照下述的要求运行。

### HS1 & HS2: 17/35跑道ILS保护区

使用17/35跑道起降时、管制员将指令滑出的 航空器在ILS保护区等待线外等待、航空器需 穿越此区域进入使用跑道前、必须得到塔台管 制员的许可。

## HS3: 滑行道A, B, C及交叉区域

航空器在此复杂区域运行时需格外小心。经滑 行道B、C脱离跑道的航空器进入该区域需识别 清楚滑行道标志,以免经滑行道B误入货机坪。 货机坪内经滑行道B滑出的航空器需识别清楚滑 行道标志、避免经滑行道B、C误入跑道。航空 器要注意管制员的等待或滑行指令, 避免进出 货机坪的航空器与经滑行道B, C脱离的跑道航 空器之间的运行冲突。

### HS4: 滑行道D和主滑A交叉区域

航空器在此复杂区域运行时需格外小心。经滑行 道D(西侧)脱离跑道的航空器及机坪内经滑行道 D(东侧)滑出的航空器进入该区域需识别清楚滑 行道标志,避免对头滑行或误入跑道。 经滑行道 A滑行的航空器进入该区域前,注意管制员的等 待或者滑行指令。

# HS5: 滑行道A, A6, A7, E及交叉区域

从停机坪经滑行道A6、A7滑出的航空器进入该区 域前,注意管制员的等待或者滑行指令,避免与 经滑行道E脱离的航空器对头滑行;同时应注意 识别清楚滑行道标志、避免经滑行道E误入跑道。 经滑行道A滑行的航空器进入该区域前,注意管 制员的等待或者滑行指令。

For the purpose of reducing errors that lead to ground conflicts and runway incursions, aircraft

operating within the maneuvering area of Qingdao airport must follow the requirements below:

### HS1 & HS2:Runway 17/35 ILS PROTECTED AREA.

Aircraft taxiing from apron will be instructed to hold short of ILS protected area outside RWY holding positions when runway 17/35 is in use. In that case, aircraft shall not proceed beyond RWY holding positions without ATC clearance.

### HS3: INTERSECTIONS OF TAXIWAYS A, B, C

Aircraft operates in this complex area must be cautious. While vacating runway via TWYs B or C, pilot shall pay attention to identify the taxiway sign-board, and avoid entering cargo apron via TWY B. While exiting out of cargo apron via TWY B, pilot shall pay attention to identify the taxiway sign-board, and avoid entering RWY via TWYs B or C. Pilot shall pay attention to ATC holding or taxiing instructions, and avoid the conflict BTN aircraft entering/exiting cargo apron and aircraft vacating runway via TWYs B or C.

### HS4: INTERSECTIONS OF TAXIWAYS A, D

Aircraft operates in this complex area must be cautious. While vacating runway via west TWY D or exitng out of apron via east TWY D, pilot shall pay attention to identify the taxiway sign-board, and avoid a head-on conflict or RWY incursion. Aircraft taxiing on main TWY A shall pay attention to ATC holding or taxiing instructions before entering this area.

### HS5: INTERSECTIONS OF TAXIWAYS A, A6, A7 and E

Aircraft exiting out of apron via TWY A6, A7 shall pay attention to ATC holding or taxiing instructions before entering this area, and avoid a head-on conflict with aircraft vacating TWY E; Pilot shall pay attention to identify the taxiway sign-board, and avoid entering RWY via TWY E. Aircraft taxiing on main TWY A shall pay attention to ATC holding or taxiing instructions before entering this area.

Changes: New chart.