ATIS - 124.150 CLD - 118.950 /118.500 AERODROME GROUND TWR - 118.100 /118.500 APRON ELEV LISBOA / LPPT GND - 121.750 /118.500 MOVEMENT CHART - ICAO 114M TAXI ROUTE PROCEDURES ARRIVAL / DEPARTURE RWY21 **HOTSPOT ARRIVAL RWY21**  Pilots should plan their landing to vacate RWY21 via TWY "HS", in order to minimize runway occupancy time, except by TAXIWAY agreement of ATC.

- If, for any particular reason, you wish to vacate via taxiway "S1" or RWY17, make the request on first contact with TWR. CAUTION! RUNWAY CAUTION! DO NOT CROSS/ENTER RWY 03/21 WITHOUT ATC CLEARANCE. VAR.4° W2006 "42" "60" "50" (RWY 17/35-2304 x 45m Asphali 70 IN ORDER TO AVOID JET BLAST HAZARDS, IF NOT CLEARED TO CROSS/ENTER RWY17/35, AIRCRAFT SHALL STOP AND HOLD PARALLEL WITH RWY 17/35 BEFORE TWY "G1","Y","M1" OR "K". MILITARY APRON WHEN TAXIING ON RWY35 DO NOT CROSS/ENTER RWY 17/35 WITHOUT ATC CLEARANCE. APPROACHING TWY "U2"/"U3", CAUTION, RWY03/21 IS AHEAD!

Text Box und

© NAV Portugal, E.P.E. AIRAC 006-13