


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

ABAKAN, RUSSIA  
ABAKAN  
RWY 02R

TRANSITION  
LEVEL : 1



RADAR START (Additionally serves as TAXIING) 134.3 122.0

1 TRANSITION LEVEL:  
- FL070 when atmospheric pressure is 724mm mercury column or above;  
- FL080 when atmospheric pressure is less than 724mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES  
DISTANCES ARE IN KILOMETRES

CHANGE: New chart