


AREA CHART - ICAO

ARRIVAL, DEPARTURE
AND TRANSIT ROUTES

MARY, TURKMENISTAN

TMA MARY



MARY RADAR	124.0	WARNING Altitudes of crossing AWY entry/exit points are as directed by ATC.
MARY METEO	128.3	

BEARINGS AND TRACKS ARE MAGNETIC
 ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES AT 6000 OR BELOW
 DISTANCES ARE IN KILOMETRES
 FLIGHT LEVELS (FL) ARE IN FEET AT FL210 OR ABOVE