
RUSSIA AND CIS

AIRCRAFT PARKING CHART - ICAO

TOWER 118,100 **GROUND** 119.000 KHANTY-MANSIYSK, RUSSIA

KHANTY-MANSIYSK



Not to scale

APRON:

Surface: Asphalt-Concrete Strength:

- PCN 34/F/B/X/T Passenger apron Cargo apron - PCN 38/F/B/X/T

TAXIWAYS:

Width: 1, 2 - 23.0m

1, 2 - Asphalt-Concrete 1, 2 - PCN 38/F/B/X/T Surface: Strength:

WARNING:

- 1. Stands 1-3, 16, 17 are AVBL for parking of Mi-2, Mi-8, Ka-32 HEL and class below HEL.
- 2. Stands 16, 17 are AVBL for parking of Mi-10, Mi-26 HEL and class below HEL.
- 3. Taxiing into stands 16, 17 shall be carried out by towing, taxiing out of these stands under own engines power.
- 4. Stands 14, 15 are equipped with aerobridges.
- 5. Before engines start-up:
 - ACFT shall be towed from stand 15 onto stand 3 or stand 4 or to the "End of Push" sign in the vicinity of stand 1;
 - ACFT shall be towed from stand 14 to the "End of Push" sign
- in the vicinity of stand 7. 6. When stand 15 is occupied, Tu-204 ACFT shall taxi into stand 2 $\,$ as follows:
 - by towing , when stand 1 is occupied;
 - under own engines power, when stand 1 is vacant. Taxiing of Tu-204 ACFT out of stand 2 shall be carried out

 - under own engines power, when stands 1 and 3 are vacant;
 by towing to the "End of Push" sign in the vicinity of stand 1, when stands 1 and 3 are occupied.
- 7. Air taxiing of HEL over the passenger apron is prohibited.
- 8. When towing engines start-up of ACFT is prohibited.

ACFT types: A-319, B737, CRJ-100, CRJ-200 B757-200, Tu-204 A-320, A-321 Tu-154 Tu-134 II-76 II-18 ATR-72 ATR-42 An-74, An-30, An-148 An-26, An-24

An-12 Yak-42 Yak-40 and other class 3, 4 ACFT

Yak-40 and class below ACFT Gulfstream 4SP, Gulfstream 5, SAAB-2000 EMB-120, L-410, Cessna Caravan

2-**4** 1-4, 14-17 1-4, 8-10, 13-17 1-4, 14-17 1-4, 8-10, 13-17 2, 4 2-4, 14, 15 1-4, 14-17

STANDS:

1-4, 14-17

2, 4, 14-17 2, 4, 14, 15

2-4, 14, 15

16, 17

15

5-13

1-4, 14-17 1-17