


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : **1**

NIZHNEVARTOVSK, RUSSIA
NIZHNEVARTOVSK
NDB RWY 21



1 TRANSITION LEVEL:

- FL040 when atmospheric pressure is 755mm mercury column or above.
- FL050 when atmospheric pressure is 728mm or above but is less than 755mm.
- FL060 when atmospheric pressure is less than 728mm.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: ELEV, COORD