




# AIRCRAFT-PARKING CHART-ICAO

ATIS 126.6  
TWR 124.35(118.1)  
GND 121.65  
121.8 for delivery

ZHHH WUHAN/Tianhe

**Note:**

1. A/C are strictly forbidden to enter RWY by TWY B2.
2.  : stand for isolated A/C.
3. All parking stands (except Nr. 215-216) can be used for engine idle test.
4. **A** **B** can be used for aircraft with wing span not more than 36m to conduct fast engine run-ups and engine idle test.  
**A** for aircraft nose to south.  
**B** for aircraft nose to north.
5. Stand Nr.223A: stand for Airbus A380.
6. Stand Nr.224: stand for aircraft cleaning.
7. Symbol " | " : H1-H4 holding positions.
8. **HS1** - **HS5** : Hot spot.
9.  TWR blind zone



Changes: Add hot spot, add TWR blind zone.