STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : **FL050**

KRASNODAR, RUSSIA
PASHKOVSKIY
RWY 05R



APPROACH	**129.600**	**127.700**
RADAR	**121.300**	
TOWER	**118.200**	

1 WARNING
Only for Russian users of airspace.

CHANGE: FREQ LMM

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES