STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

SARATOV, RUSSIA
TSENTRALNY
RWY 30



RADAR **120.400**
TOWER **128.100**

❶ TRANSITION LEVEL:
- FL040 when atmospheric pressure is 746mm mercury column or above;
- FL050 when atmospheric pressure is less than 746mm mercury column and is 719mm mercury column or above;
- FL060 when atmospheric pressure is less than 719mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: New chart